


# Sound Booth Patch Panel Wiring Diagram



1 - NW corner unused  
2 - NW corner unused  
3 - Internet (Netgear MS-2)  
4 - Camera 2 HDMI

5 - Camera 2 PoE  
6 - W wall unused  
7 - NEC P452 (HDMI)  
8 - Front ceiling unused

19 - Front ceiling unused  
Outdoor WAP - Netgear WAX610Y  
Rear- A Epson L260F(HDMI)  
Rear- B unused