











Sound Booth Start-Up Procedure

Revised 26Mar26

Working from right to left, standing in the Sound Booth:

<p>#</p> <p>1</p>	<p>Turn on the LIVESTREAM2 computer monitor by sliding your finger along the bottom of the lower monitor bezel from right to left. When you hit the first button on the bottom of the bezel, press it to turn on the monitor.</p>	
<p>2</p>	<p>Repeat Step #1 with the next monitor to the left. This turns on the MultiView monitor screen</p>	
<p>3</p>	<p>Turn on power to the Livestreaming equipment using the power switch on PDU-2 in the equipment rack. This PDU powers the following equipment</p> <ul style="list-style-type: none"> • Wireless microphone receivers • ATEM Min Extreme video switch • TASCAM mixer • PTZ cameras 1 and 2 • SuperJoy Joystick • The lamp next to SANCTAV4 computer • Apple TV • Netgear PoE switch SW-1 • OREI HDMI splitter • goFanco, OREI and LINK HDMI extenders 	
<p>4</p>	<p>Turn on the PA amplifier by pressing the button between the two channel volume knobs on the front of the amp.</p>	

<p>5</p>	<p>If it was not left powered on, turn on the camera operator's monitor by pressing the button on the FRONT right lower portion of the monitor bezel.</p>	
<p>6</p>	<p>Turn on the slide show SANCTAV4 computer monitor by sliding your finger along the bottom of the lower monitor bezel from right to left. When you hit the first button on the bottom of the bezel, press it to turn on the slide show computer monitor.</p>	
<p>7</p>	<p>Turn on the wall camera microphone (over near the piano) by sliding the ON/OFF switch (leftmost switch) from top to bottom. A blue light will come on when the microphone is ON. If the blue light does not come ON, replace the battery by unscrewing the end cap and replacing the single AA rechargeable battery. Observe polarity. The positive battery terminal points out.</p>	
<p>8</p>	<p>Turn on the rear-facing Epson projector by using the Epson remote which is in a box on the shelf in the Sound Booth.</p>	

9	Turn on the front-facing NEC projector by using the NEC remote which is in a box on the shelf in the Sound Booth.	
10	In the Narthex . . . Turn on the Narthex TV by using the Vizio remote. The Vizio remote is on a slide-out tray in the coffee table.	

Congratulate yourself on a job well done! 😊

Revised
nmh 26Mar26